

Congratulations on your purchase of a ATG DJ speaker. Your selection of an ATG Product indicates a true appreciation of music.

KEEP YOUR SALES RECEIPT

Take this time to attach your sales receipt to the manual and put in a safe place. In case of and unforeseen reason this product may need warranty service, your receipt will be necessary to establish a purchase date.

1. Warning: Do not open the unit case, damage to the internal circuits could result from doing so. There are no user serviceable parts inside. Failure to comply with this warning will result in warranty being void.
2. Ventilation: for proper operation the unit must have at least 12 inches of ventilation space around all sides. Do not enclose the unit with any type of material as this could cause the power amplifier to overheat and could result in failure.
3. When handling the power charging cord, use special care to handle the plug firmly. Do not pull from any other location other than the plug ends.
4. If the unit is not operating properly, it may require service. For service, please contact the establishment it was purchased from.

FEATURES

- Plays AUX IN files stored in Media Card / Media Drive / External Audio device
- FM Radio
- Guitar Input
- Microphone Input
- Wireless Microphone Included
- Remote Control
- Built-In 12V/7A Rechargeable Battery
- Microphone Priority On/Off Switch
- Super Dynamic Sound Speaker
- WP Connection


CONNECTING

1. This set applies to AC 110V-240V, 50/60Hz
2. AC Power: Battery can be charged when connected to AC power. Red Light on battery is charging, it will change to green once battery completely charges.
3. Internal Battery will be charged even when device is off.
4. Speaker battery can be charged using 12V external car battery as well (12V charging cable not included) by "DC12V Input." Please make sure "+" and "-" in right connection.
5. Adjust function keys to your personal audio preference.


WIRELESS CONNECTION

Change the mode into "BLUE," the wireless sign light flashes and speaker will give an audible beep alarm. Ensure you enable the media function on your wireless device. Search for media connection until you find device model and pair.

WIRELESS PAIRING (WP) CONNECTION

STEP 1  Push the Mode Button on both speakers until speakers are in Media Mode. Screen will display the word "BLUE".

When both speakers are in Media mode, push and hold the WP/SCAN button for 3 seconds. You will hear a beep & screen display "bt/btst". Next time you put both speakers in Media mode at the same time, speakers will connect automatically.

STEP 3  On your device, turn your Media settings "ON", you will then select the unit and pair. Enjoy WP (Wireless Pairing) sound from your phone wirelessly!

BATTERY & CHARGING

1. The unit takes approximately 8 hours to fully charge. It will automatically begin charging once the power cord is connected.
2. Low battery level may result in distorted sound, for best acoustical performance please monitor battery charge level.
3. To maximize the battery's lifespan, please charging the battery immediately when the unit is not used for prolonged periods of time, the battery will gradually lose its power. It is recommended to fully charge the battery at least every 30 days.


REMOTE CONTROL



- ⏻ Standby
- 📀 Media Audio input
- ⏮ CH- Prev / FM Ch-
- ⏸ Play / Pause / FM Tuner
- ⏭ CH+ Next / Fm Ch+
- 🔄 Repeat
- ⏹ Stop
- 🔊 Volume Up
- 🔊 Volume Down
- 🔇 Mute
- 🎛 Equalizer
- 1-0 Number


4

ATGDJ15



- ① VOLUME: Master Volume Adjust
- ② TREBLE: Treble Adjust
- ③ BASS: Bass Adjust
- ④ MIC PRIORITY: Microphone Priority On / Off switch
- ⑤ ECHO: Echo Adjust
- ⑥ MIC VOLUME: Microphone Volume Adjust
- ⑦ GUITAR VOLUME: Guitar Volume Adjust
- ⑧ MIC IN/GUITAR IN: Microphone Input / Guitar Input
- ⑨ MEDIA Input
- ⑩ MEDIA PANEL FUNCTION:
 - ≡ Mode Select
 - 📀 Record - Insert the Media card and press this button to start recording. Pressing the button again stops recording.
 - ⏮ Repeat Select
 - ⏸ Play/Pause; FM Station Auto Searching WP Scan
 - ⏮ Previous
 - ⏭ Next

ATGDJ12



- ⑪ 12v EXTERNAL INPUT
- ⑫ AUX IN
- ⑬ EXTERNAL AUDIO JACK
- ⑭ WIRELESS MICROPHONE ANTENNA
- ⑮ FM ANTENNA
- ⑯ POWER SWITCH
- ⑰ AC POWER INPUT: Universal 110-240V/50-60Hz
- ⑱ LED LIGHT On / Off Switch

5



LIMITED WARRANTY

ATG warrants any products purchased in the U.S.A. from an authorized ATG dealer. All products are warranted to be free from defects in material and workmanship under normal use and service for a period of one (1) year when purchased over the counter. This warranty applies to the original purchase only.

ATG will either repair or replace (as its option) any unit that had been found to be defective and under warranty provided the defect occurs within the one (1) year warranty period.

Limited warranty period does not extend to units having been subjected to misuse, abuse, neglect, or accident. In ATG's judgment, products that show evidence of having been altered, modified, or serviced without ATG's authorization, will be ineligible under this warranty.

To obtain warranty services please contact your retailer or visit our website at www.ATG-Audio.com for more details.



ATG Audio-to-Go
616-878-3900 / www.ATG-Audio.com / support@atg-audio.com